

# Avanti™

## Quick Set

This feature allows the panel to be **SET** so that it overrides the programmed exit time. Entering an access code, selecting Program **A / B** or **\*** and then pressing **⏸** will cause the panel to **SET** within 2 seconds.

## Holiday Access Code

The purpose of this code is to allow access to the property whilst the manager is absent. The Holiday Access Code is programmed by the Manager and is only valid until the Manager **UNSETS** the system. At this point the Holiday Access Code becomes invalid and is no longer accepted by the control panel.

## User Codes

A User can perform the same operations as a Manager **except** they are unable to View the Event Log, access the Test Menu or change Access Codes. If a User does not select a program when setting the panel then the system will default to **Full Set**. **(NB a Manager must select a program.)**

## On board PA

Simultaneously depressing key's **4** and **8** will activate a **PA** thus creating a full alarm condition. This feature can be used when the system is in **DAY** mode or **SET**. (If you have an RS Panel fitted with a communicator then a signal will also be sent.)

Additionally RS Panels have individual duress codes for the Users, Holiday and Manager. Duress is only accessible in **SET**. Entering an access code followed by the **first** digit within 1 to 1.5 seconds will activate a silent **PA**. i.e.: - **0 1 2 3 0**

## Call Engineer

The panel may have been programmed to display that the system may require a service. If the **Tamper LED flashes** then you should contact your engineer. If the Tamper LED is flashing this does not affect the operation of the system. **(NB if you have an RS panel then the Tamper LED flashing could indicate that you have a line fail and you should contact your engineer.)**

## Fault during setting

If the system is unable to **SET** then the internal sounders will make an error tone. The fault on the system will be indicated by the relevant zone/PA/Tamper LED being lit. If a zone LED is lit then ensure that all windows and doors are closed and the zone is clear. If the fault persists then it may be possible to omit the zone. It is advisable to contact your engineer for further information.


## Alarm Activation

If the system has been activated then an access code needs to be entered. To reset the system all that is required is to re-enter an access code.

## Chime

From **DAY** mode chime may be changed in the following way: Press **⏸**. All of the zones that chime when they are activated will have their LED lit. Press the key that represents the zone that you require. When the LED is lit, that zone will chime upon activation. Press **A** To Accept / Press **B** To Abort the changes.

## Avanti™ Manager Operating guide



Avanti and mdt are trademarks of mdt ltd